

- WIRING INSTRUCTIONS—
fail secure strike with button and keypad
wired in parallel

